

RESETTING TRIPS

IN DR and RICH

1. Open the **Detector-Based Adjustment Frame** GUI
2. If there are channels listed in the lower half of the window, press '**Clear All**' for the system they belong to.
3. Select the tripped channels.
4. Right click on **BEN** column and change value to 0 to disable bulk.
5. Hit '**Refresh**' a few times to make sure the **BEN** column goes to 0
6. Continue to Hit '**Refresh**' until **BMV** is below 100 Volts
7. Right click on **CEN** column and change value to 1 to reset the trip.
8. Hit refresh several times and make sure trip is reset.
9. Right click on **BEN** column and change value to 1 to ramp up the HV.
10. Any Questions? PLEASE CALL THE HV EXPERT!