

## CESR-CLEO HV Interface Hardware

### Address Map

**Base address:** Set by switch on HV Interface board, **A[15..4]** = (0x0510)

**Address Decoder:** A[3..0] decodes functions on the VME board

<u>A[3..0]</u>	<u>R/W</u>	<u>Description of Function</u>
0x0	R	Read Board ID (constant set in Altera chip)
0x1	R	Read Board ID (ID = 46 = 0x2E)
0x2	R	Clears counter; Reads <b>csr[3..0]</b> <b>CSR 0</b> = Timeout Clear <b>CSR 1</b> = Timeout Set <b>CSR 2</b> = CESR INHIBIT (Output) <b>CSR 3</b> = Timeout has occurred (FAIL) <b>CSR 4</b> = CESR HV ENABLE (Input)
	W	D0 = 1 forces a clear of timeout (nFAIL = 1)
	W	D1 = 1 forces a timeout (nFAIL = 0)
	W	D2 = 1 sends an inhibit to CESR
0x3	R	Read Watchdog Timeout (in seconds)
	W	Write Timeout value (in seconds)
		<b>NOTE:</b> Setting TO value to 0 will always generate a TO

### Additional notes

There are 3 ways to Timeout:

- 1) The timer counts up to the Timeout value, after which it will force a Timeout FAIL condition.
- 2) Writing a Timeout value of zero will always generate a Timeout FAIL
- 3) Write to A[3..1] = 2 and D[2..0] = 0x2 (Set TMO SET bit)

To clear the Timeout FAIL:

- 1) Write a nonzero Timeout value to the Watchdog Timer.  
Write to A[3..1] = 2 and D[2..0] = 1  
(Set TMO CLR bit to clear the previous FAIL)  
You also need to write A[2..0] = 2, D[2..0] = 0 to clear the CSR and release the TMO clear bit. To start the timer again.  
(At this stage, you may also set the INHIBIT).


To keep the Watchdog Timer from Timing Out, you need to hit it:

- 1) Clear counter by reading  $A[3..0] = 2$ .


You can double-check this value to see the CESR HVENable status and also double-check that there is no Timeout FAIL.

Note: The INHIBIT is cleared by the assertion of FAIL. If the HV Server stops running for some reason and the watchdog times out, not only is the FAIL asserted, but the INHIBIT is also released.

*The OLD HV enable signal worked like this:*



*The NEW HV enable signal works like this:*



In a **FAIL** condition, the CESR HV ENABLE line connects to the CLEO HV ENABLE line.

The logic is as follows. If the CLEO HV program stops hitting the watchdog timer, the interlock board will generate a FAIL condition which connects the CESR HV ENABLE to the CLEO HV. If the CLEO HV Server can't hit the watchdog, it means that the CLEO HV Slow Control system is no longer capable of controlling that status of its HV

(turning the HV ON and OFF). The FAIL condition allows CESR to control the HV for us.

During normal running, the HV Server will continually be hitting the watchdog timer (reading the CSR) to keep the Interlock board from timing out. This will keep the control of the HV in the hands of the CLEO HV Slow Control. Should the CLEO HV Server break and stop hitting the watchdog, the CLEO HV control will pass into the hands of CESR (through the HV ENABLE line).

The other line shared by the CESR-CLEO HV Interlock and CESR is the INHIBIT. The INHIBIT can keep CESR from filling, etc. while the HV system is ramping or is in some other intermediate state.

What happens when you first turn the CESR-CLEO HV Interlock board on?

**fbff0510:** 002E      ADR[0] = Board ID = 0x2e = 46  
**fbff0512:** 002E      ADR[1] = Board ID = 0x2e = 46  
**fbff0514:** 0018      ADR[2] = CSR = 0x18  
                          **CSR 0** = 0 = Timeout Clear  
                          **CSR 1** = 0 = Timeout Set  
                          **CSR 2** = 0 = CESR INHIBIT (Output)  
                          **CSR 3** = 1 = FAIL  
                          **CSR 4**        = 1 = CESR HVEnable: no cable

plugged in

**fbff0516** 0000      ADR[3] = Timeout Value = 0

What happens after a Timeout Fail?

Same as power-up conditions above with one exception:

**Timeout value remains unchanged.**

Example: If timeout value was 0x10 before the Timeout then **fbff0516** will read back 0x10 after the timeout as well.

What happens if the power to the CESR-CLEO HV Interlock crate is turned off?

The Server running on that ppc will go away. I don't know how this affects us or how to tell when this happens yet.

The CESR HVENABLE switch is CLOSED which means the CESR and CLEO lines are connected. (There is 0Ω resistance between the centers of the two connectors.

The CESR INHIBIT switch is also CLOSED so the resistance between inner and outer barrels on the connector is 0Ω.

**We will not be able to read out these values!!!!**

What are the values of the switches INHIBIT and HVENABLE switches?

**Power is ON:**

FAIL = 1      R = 0 Ω      (R is the resistance between the centers of

FAIL = 0       $R = \infty$       the HVEnable connectors).


INHIBIT = 1    $R = \infty$       (R is the resistance between the inner and  
INHIBIT = 0    $R = 0 \Omega$       outer barrel of the connector).

**Power is OFF:**

FAIL               $R = 0 \Omega$

INHIBIT         $R = 0 \Omega$

## Front panel and LED's



*Select* LED flashes green whenever the board is addressed

There is a 10-pin *Altera header* on the board for reprogramming the Altera chip. It is accessible through the front panel

*HVENable* is a green LED which is ON whenever FAIL is NOT asserted. Therefore, it is on whenever CLEO has control over its own HV and

*INHIBIT* is a red LED which is ON when the INHIBIT relay is open and OFF when the relay is closed